

PT6

Nitrate/Temperature

NEW! ULTRAPEN™ PT6



Actual Size

ALSO AVAILABLE!

ULTRAPEN™ PT1
Conductivity, TDS, Salinity
& Temperature



ULTRAPEN™ PT3
ORP & Temperature




ULTRAPEN™ PT5
DO (Dissolved Oxygen)
& Temperature



ULTRAPEN™ PT2
pH & Temperature



ULTRAPEN™ PT4
Free Chlorine Equivalent (FC¹)
& Temperature



BENEFITS:

- Reliable Repeatable Results
- Accurate
- Affordable
- Easy to Use
- Rugged Design
- Ensure Product Quality
- Reduce Waste
- Protect the Environment

HIGH PERFORMANCE FEATURES:

- Nitrate Concentration (ppm N or ppm NO₃⁻) or mV
- 1 and 2 Point Calibration Options
- Proprietary ISE Sensor Design
- Built-in Double Junction Reference Electrode
- Compatible with EPA Approved Standard Method 4500-NO₃⁻ D
- Live or Hold Mode - User Selectable
- Auto-Off Feature – User Adjustable
- Easy to Use - One Button Control
- Rugged Design with Aircraft Aluminum Body
- Durable, Epoxy Encapsulated Electronics
- Waterproof
- Powered by One N Type Battery (Included)

PT6 COMES WITH:

- PT6 Pocket Tester Pen - Battery Installed
- User Replaceable Nitrate Sensor – Installed
- 100 ppm NO₃⁻-N Standard Solution – 2 oz.
- Ionic Strength Adjuster (ISA) – 2 oz.
- Graduated Cylinder with Cap – 2 ea.
- 100 µL Pipette – with Tip
- Protective Cap
- Pocket Clip
- Lanyard
- PT6 Operation Manual



DESIGNED, ENGINEERED
AND ASSEMBLED IN THE USA

MYRON L[®]
COMPANY
Water Quality Instrumentation
Accuracy • Reliability • Simplicity
... Since 1957


PT6 MEASUREMENT MODES

MODE	METHOD OF MEASUREMENT
Hold	Displays real-time readings until the LED turns solid ON, then displays final readings.
LIVE	Displays real-time readings continuously for up to 5 minutes.

PT6 PARAMETER MODES

MODE	PARAMETER MEASURED
N	Display alternates between Nitrate as Nitrogen (NO ₃ ⁻ -N), and Temperature
NO3	Display alternates between Nitrate (NO ₃ ⁻), and Temperature
mV	Display alternates between millivolt (mV), and Temperature

SPECIFICATIONS

	Nitrate as Nitrogen NO ₃ ⁻ -N	Nitrate NO ₃ ⁻	Temperature
Ranges	1-1400 ppm	4.4-6200 ppm	0 - 71°C / 32 - 160°F
Accuracy ¹	±10% of the reading	±10% of the reading	±0.1°C
Resolution	0.1 ppm	0.1 ppm	0.1°C/F
pH Range: 3-11 pH			
Time to Reading Stabilization: 10 - 180 seconds			
Power Consumption: Active Mode: 30 - 140 mA, Sleep Mode: 2 µA			
Physical Dimensions: 17.15 cm L x 1.59 cm D or 6.75 in. L x .625 in. D			
Weight: 54 g or 1.94 oz.			
Case Material: Anodized Aircraft Aluminum with Protective Coating			
Battery Type: N type, Alkaline 1.5 V			
Calibration Standard Solutions: 1, 10, 100, or 1000 ppm NO ₃ ⁻ -N			
Operating / Storage Temperature: 0-40°C / 32-104°F ²			
Enclosure Ratings: IP67 and NEMA 6			
EN61236-1: 2006 - Annex A: 2008; Electrostatic discharge to case of instrument may cause PT6 to spontaneously power ON. In this case, the PT6 will power OFF after several seconds. CE			
 WARNING! These products can expose you to chemicals including Di(2-ethylhexyl)phthalate (DEHP), which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov .			

¹ Accuracy of measuring standard solutions after Temperature Controlled, 2-Point Calibration with one order of concentration difference.

² For extended life of the sensor, store the pen in a cool location (5-25°C)

ACCESSORIES

STANDARD SOLUTIONS FOR CALIBRATION:

The ULTRAPEN™ PT6 can be calibrated with 1, 10, 100, or 1000 ppm NO₃⁻-N Calibration Solution

Order Models:

- N1SOL - 1 ppm NO₃⁻-N (Nitrate as Nitrogen) Standard Solution
- N10SOL - 10 ppm NO₃⁻-N (Nitrate as Nitrogen) Standard Solution
- N100SOL - 100 ppm NO₃⁻-N (Nitrate as Nitrogen) Standard Solution
- N1000SOL - 1000 ppm NO₃⁻-N (Nitrate as Nitrogen) Standard Solution

IONIC STRENGTH ADJUSTER:

Order Model: NISASOL

NITRATE INTERFERENCE SUPPRESSION BUFFER:

Order Model: NISBSOL

REPLACEMENT NITRATE SENSOR:

Order Model: RPT6

MYRON L® WARRANTY

The PT6, excluding the sensor and battery, has a one (1) year limited warranty.

The Nitrate sensor has a six (6) month limited warranty.

2450 Impala Drive
 Carlsbad, CA 92010-7226 USA
 Tel: +1-760-438-2021
 Fax: +1-800-869-7668 / +1-760-931-9189
www.myronl.com

Built On Trust. Founded in 1957, the Myron L® Company is one of the world's leading manufacturers of water quality instruments. Because of our commitment to product improvement, changes in design and specifications are possible. You have our assurance any changes will be guided by our product philosophy: accuracy, reliability, and simplicity.

